

ROUND FIRE PIT KIT



SQUARE FIRE PIT KIT




ROUND FIRE PIT Matches Belvedere Texture




Round Fire Pit Pallet: 1,275 lbs


TOP VIEW



CROSS-SECTION



BLOCK LAYOUT PATTERN FOR ROUND FIRE PIT



INSTRUCTIONS: For Both Round & Square Fire Pit Kits


1. Familiarize yourself with the construction details shown on this page.
2. Mark out the location for your fire pit. Note dimensions shown are nominal so mark an area slightly larger than shown.
3. Excavate for drain stone base (approx. 6")
4. Fill excavated area with drain stone, level, and compact.
5. Place and center steel ring on prepared base.
6. Place blocks per the pattern. (For Round Kit, keep Blocks 11 1/2" off steel ring)
7. **WARNING:** Do not place Rosetta Fire Pits directly on Rosetta Flagstone products or any comparable concrete product as high heat can adversely affect the integrity of the product.

FOLLOWING STEPS FOR ROUND FIRE PIT ONLY

8. After placing blocks around the ring, adjust the blocks in or out to make the circle close and fit tight. If the blocks do not close the circle, move all blocks slightly in. If the blocks seem too long, move the blocks slightly out.
9. Place caps in circle around fire pit. Adjust the caps in or out to make them fit tightly together.
10. Note: Not suitable for large fires. Fire size should not allow flame to contact Caps on Round Fire Pit.

\*Gas Conversion Kits Available

SQUARE FIRE PIT Matches Dimensional Wall Texture



Square Fire Pit Pallet: 1,130 lbs

